



- NOTES:
- ⚠ CONTOUR CONTROL (R18) USED ONLY IN S115R, I12R, I15R, SC12R, C15R, C12R.
  - ⚠ Q5, Q6, R25 & R26 OMITTED IN A15R, A10R, S20R, S15R, S12R.
  - ⚠ DASHED PARTS LOCATED BELOW BOARD.
  - ⚠ R32 & R33 USED ONLY IN SC12R, C15R, C12R, S20R, S15R, S12R.
  - ⚠ R44 MAY BE REQUIRED.

*Standel.*

PICTORIAL DIAGRAM  
1968

REVERB AMPLIFIERS  
S115R, I12R, I15R, SC12R, C15R, C12R, S15R, A20R  
A12R, A15R, A10R, S20R, S15R, S12R

DRAFTSMAN H.M.M.	CHECKED M.J.Q.	APP DATE REB 12-14-67	IE001
---------------------	-------------------	--------------------------	-------